



TOP VIEW

DETAIL B SCALE 1:5





FRONT VIEW

SECTION A-A

MATERIALS:
- HP-Laminate PB-5/8"
- 0.018 Edge Tape
- Plywood 1/2" Wall Cleat
- Frosted Acrylic Cover
- LED Strip 2700K-3000K
-
_

COMMENTS:

- Overall: 60"W x 3"D x 31"H
- Color: Wilsonart 8213K-18 Phantom Cocoa
 D427K-01Solicor Linen (High Gloss)
 Note:Dimensional Tolerance +/- 1/16"

TITLE: AHB 8240XX TVP60R - 8240CRS - 60" TV Panel R-Accent REVISION DATE:

NOTE: DESIGN AND DRAWINGS ARE PROPERTY OF DICKSON FURNITURE MAINTACTURERS LLC AND MAY NOT BE DUPLICATED OR REPRODUCED WITHOUT THE EXPRESS WRITTEN CONSENT OF DICKSON FURNITURE MANUFACTURERS LLC

DICKSON FURNITURE MANUFACTURERS


> SCALE: 1:10 SHEET 2 OF 4



*RECOMMENDATIONS:

- Read instructions before assembling
- Keep area clean
- Do not drag the parts
- Do not forget to wear PPE

PARTS:



*PERSONAL PROTECTION EQUIPMENT (PPE)

- Hand Protection
- Eye Protection
- Waist Support belt

*Tools:









Water level

Measuring Tape Pencil

Drill

*Hardware:



Screw





STEP #1


INSTALLATION INSTRUCTIONS

- X-270 AHB 8240XX TVP60R - 8240CRS - 60" TV Panel R-Accent -


Note: To lift TV Panel use at least 2 people







Lift TV Panel (3) higher than Center French Wall Cleats (2) and slowly slide it down until it holds on Wall.



TV Panel completely assembled.

